

# SOLIDWORKS 2011 TUTORIALS

## CHAIR



### Table of Contents

	<b>Chapters</b>	<b>Page</b>
<b>Part</b>	<b>1 Profiles.....</b>	<b>1-1</b>
<b>Part</b>	<b>2 Bottom Rail 2 x 4.....</b>	<b>2-1</b>
<b>Part</b>	<b>3 Side Rail 2 x 6.....</b>	<b>3-1</b>
<b>Part</b>	<b>4 Back Leg 2 x 4.....</b>	<b>4-1</b>
<b>Part</b>	<b>5 Front Leg 2 x 6.....</b>	<b>5-1</b>
<b>Part</b>	<b>6 Arm 2 x 6.....</b>	<b>6-1</b>
<b>Part</b>	<b>7 Top Rail 2 x 6.....</b>	<b>7-1</b>
<b>Part</b>	<b>8 Arm Support 2 x 4.....</b>	<b>8-1</b>
<b>Part</b>	<b>9 Back Slats 1 x 4.....</b>	<b>9-1</b>
<b>Part</b>	<b>10 Seat Slats 1 x 2.25.....</b>	<b>10-1</b>
<b>Part</b>	<b>11 Plugs.....</b>	<b>11-1</b>
<b>Toolbox</b>	<b>12 Toolbox Screws.....</b>	<b>12-1</b>
<b>Assembly</b>	<b>13 Assembly.....</b>	<b>13-1</b>
<b>Drawing</b>	<b>14 Drawing.....</b>	<b>14-1</b>
<b>PhotoView</b>	<b>15 Decal for Body.....</b>	<b>15-1</b>
<b>PhotoView</b>	<b>16 PhotoView 360 Rendering.....</b>	<b>16-1</b>
<b>Mastercam</b>	<b>17 SolidWorks to Mastercam X5.....</b>	<b>17-1</b>
<b>Mastercam</b>	<b>18 Body ToolPaths.....</b>	<b>18-1</b>

