



Set Toolbox Files Properties

A. sldsetdocprop.exe (SOLIDWORKS Set Doc Properties).

Step 1. If necessary, close any of your toolbox files (Bearing and Gears) in SOLIDWORKS.

Step 2. Open File Explorer.

Step 3. Navigate to Program Files/ SOLIDWORKS Corp/ SOLIDWORKS/ Toolbox/ data utilities folder

open sldsetdocprop.exe, Fig. 1.




Fig. 1

Step 4. In the Set Document Property dialog box:

click Add Files button, Fig. 2.

Step 5. In the Open dialog box:
Navigate to My Documents/
Tech Ed 22-23/Wind Turbine folder

Ctrl click the toolbox parts (3):
BEARING 0030-10
GEAR 10T
GEAR 80T
and click Open, Fig. 3.




Fig. 2




Fig. 3

8/14/22

Step 6 Back in the Set Document Property dialog box:
 under Set Document Property, **Fig. 4**
 select **Property state: No**
 click **Update Status** button.






Fig. 4

Step 7. All is good. But, if you want to confirm update, select a file and click **Show Selected Property** button, **Fig. 5**.

click **Close** button.

Step 8. In an assembly feature tree these files will now show as part icon  as opposed to the toolbox icon .




Fig. 5

Tip: Create a desktop short cut to **sldsetdocprop.exe**.




Fig. 6