




CO2 Shell Car Hair Pin Clip



A. Sketch Lines.

Step 1. Click File Menu > New, click **Part Metric** and OK.
 Step 2. Click **Right Plane**  in the Feature Manager and click **Sketch**  from the Context toolbar, **Fig. 1**.





Fig. 1

Step 3. Click **Line**  (L) on the Sketch toolbar.
 Step 4. Draw a horizontal line out to left from Origin



 and a line above at angle, **Fig. 2**.
 To terminate chain, double click back on the line you have just drawn.



Fig. 2

Step 5. Click **Smart Dimension**  (S) on the Sketch toolbar.

Step 6. Add dimensions, **Fig. 3**.

Step 7. Click Zoom to Fit  (F) on the View toolbar.






Fig. 3

B. Save as "HAIR PIN CLIP".

Step 1. Click File Menu > Save As.
 Step 2. Key-in **HAIR PIN CLIP** for the filename and press ENTER.

C. Centerpoint Arc.

Step 1. Click **Centerpoint Arc**  (S) in the Arc flyout  on the Sketch toolbar.

Step 2. Draw arc above left endpoint of horizontal line, **Fig. 4**. To draw arc, click directly above left endpoint of horizontal line to place the center of arc. Click left endpoint of line to start arc, swing around and click to place the second endpoint.






Fig. 4


D. Three Tangent Arcs.


Step 1. Click **Tangent Arc**  in the **Arc flyout**  on the Sketch toolbar.


Step 2. Draw **three chained arcs from endpoint of center-point arc**. After clicking endpoint on line, click **Make Tangent**  on the Context toolbar, **Fig. 5**.




Step 3. **Right click graphics area and click Select** from menu to unselect Arc tool.

Step 4. **Ctrl click the centerpoint of centerpoint arc and left endpoint of horizontal line** to select both. Release Ctrl key and click **Make Vertical**  on the Context toolbar, **Fig. 6**.



Step 5. Click **Smart Dimension**  (S) on the Sketch toolbar.



Step 6. Add dimensions, **Fig. 7**.



Step 7. Click **Exit Sketch**  on the Sketch toolbar.

E. Profile.

Step 1. Click **Isometric**  on the Standard Views toolbar. (**Ctrl-7**)

Step 2. Click **Front Plane**  in the Feature Manager and click **Sketch**  on the Context toolbar, **Fig. 8**.





Fig. 8

Step 3. Click **Circle**  (S) on the Sketch toolbar.

Step 4. Draw a circle at Origin , **Fig. 9**.

Step 5. Click **Smart Dimension**  (S) on the Sketch toolbar.

Step 6. Dimension **diameter 1.04**, **Fig. 9**.

Step 7. Click **Exit Sketch**  on the Sketch toolbar.






Fig. 9

F. Sweep.

Step 1. Click **Features**  on the Command Manager toolbar.

Step 2. Click **Swept Boss/Base**  on the Features toolbar.




Fig. 10

Step 3. In the Swept Boss/Base Property Manager:
under Profile and Path, **Fig. 10**

Profile  click circle, **Fig. 11**

Path  click any geometry in **Sketch1**

click OK .





Fig. 11

G. Material Steel 304.

Step 1. **Right click** **Material**  in the Feature Manager and click **Edit Material**.

Step 2. Expand **Steel** in the material tree and select **Steel AISI 304**. Click **Apply** and **Close**.

Step 3. Save. Use **Ctrl-S**.




Fig. 12