



# SOLIDWORKS 10 TUTORIALS

## Airplane

### Table of Contents

<b>Chapters</b>		<b>Page</b>
<b>Part</b>	<b>1</b>	<b>Fuselage.....1-1</b>
<b>Part</b>	<b>2</b>	<b>Wing .....2-1</b>
<b>Part</b>	<b>3</b>	<b>Horizontal Stabilizer .....3-1</b>
<b>Part</b>	<b>4</b>	<b>Vertical Stabilizer.....4-1</b>
<b>Part</b>	<b>5</b>	<b>Motor .....5-1</b>
<b>Part</b>	<b>6</b>	<b>Wheel.....6-1</b>
<b>Part</b>	<b>7</b>	<b>Wheel Wire .....7-1</b>
<b>Assembly</b>	<b>8</b>	<b>Landing Gear Sub-Assembly .....8-1</b>
<b>Assembly</b>	<b>9</b>	<b>Assembly .....9-1</b>
<b>Drawing</b>	<b>10</b>	<b>Drawing .....10-1</b>
<b>Part</b>	<b>11</b>	<b>Elevator with Mates.....11-1</b>
<b>Part</b>	<b>12</b>	<b>Rudder with Mates .....12-1</b>
<b>Part</b>	<b>13</b>	<b>Propeller with Mates.....13-1</b>
<b>Part</b>	<b>14</b>	<b>Tail Hook Wire with Mates .....14-1</b>
<b>PhotoWorks</b>	<b>15</b>	<b>Fuselage Decal .....15-1</b>
<b>Flow Sim</b>	<b>16</b>	<b>Analyze in Wind Tunnel .....16-1</b>
<b>Mastercam</b>	<b>17</b>	<b>SolidWorks to Mastercam X4 .....17-1</b>
<b>Mastercam</b>	<b>18</b>	<b>Fuselage Finish Blend ToolPaths .....18-1</b>
<b>MCX4 for SW</b>	<b>19</b>	<b>Fuselage Finish Raster MA 90 .....19-1</b>
<b>MCX4 for SW</b>	<b>20</b>	<b>Fuselage Finish Raster MA 0 .....20-1</b>
<b>CAMWorks</b>	<b>21</b>	<b>CAMWorks Fine Toolpaths .....21-1</b>

